MASTER

MONOCOQUE.

Issue	Signature	D
1	R. Sutton	14.

MONOCOQUE ASSEMBLY - 802

SECTION

	Item	Part No	DRG No.	No. Off	Detail
1	FRONT BULKHEAD	45-15-13	802-01-13	1	
2	M.F.B.H. R.H.	45-15-12	802-01-08	1	
3	M.F.B.H. L.H.	45-15-11	802-01-07	1	
4	FRONT BOTTOM DAMPER/B.HEAD INSERT	4-96-3	803-01-84	2	
5	FRONT BULKHEAD BEAM	45-15-14	802-01-14	1	
6	FRONT CRASH HOOP	45-12-8	803-01-29	1	
7	" " " DOUBLER L.H.	45-15-5	803-01-47	1	
8	" " " " R.H.	45-15-4	803-01-48	1	
9	FRONT SUSPENSION EAR	4-92-11	803-01-13	2	
10	REAR BULKHEAD L.H.	45-16-1	802-01-09	1	
11	" " R.H.	45-16-2	802-01-10	1	
12	REAR BUTRESS L.H.	45-16-7	802-01-11	1	
13	" " R.H.	45-16-6	802-01-12	1	
14	INNER SKIN	45-15-15	802-01-15	1	
15	OUTER SKIN TOP L.H.	45-16-3	802-01-19	1	
16	" " " R.H.	45-16-4	802-01-20	1	
17	" " BOTTOM L.H.			1	
18	" " " R.H.			1	
19	REAR PANEL	45-16-5	802-01-18	1	
20	SEAT BACK PANEL	45-10-7	792-01-53	1	
21	FRONT TOP PANEL	45-15-3	803-01-10	1	
22	STEEL TOWER SIDE L.H.	45-13-3	803-01-31	1	
23	" " " R.H.	45-13-2	803-01-30	1	
24	SEAT BACK STIFFENER	45-13-14	803-01-62	1	
25	SEAT BACK CORNER STIFFENER L.H.	45-13-15	803-01-63	1	
26	" " " " R.H.	45-14-2	803-01-64	1	
27	F.B.H./INNER SKIN BRKT L.H.	45-13-9	803-01-77	1	
28	" " " " R.H.	45-13-8	803-01-76	1	
29	FOOT BOX STIFFENER L.H.	45-14-1	803-01-25	1	
30	" " " R.H.	45-14-4	803-01-24	1	
31	" " TOP PANEL	45-13-7	803-01-55	1	
32	RACK HOLE DOUBLER L.H.			1	
33	" " " R.H.			1	
34	PEDAL BRACKET BASE	45-13-6	803-01-52	1	
35	PEDAL CHANNEL L.H.	45-14-15	803-01-53	[illegible]	
36	" " R.H.	45-14-14	803-01-[illegible]	3	

MONOCOQUE

Issue	Signature	Date
1	R. Se[illegible]	[illegible]

MONOCOQUE ASSEMBLY - 802

Sheet 2 of 3

	Item	SECTION Part No	DRG No.	No. Off	Detail
37	FRONT SUSPENSION BOX FLOOR L.H.			1	
38	" " " " R.H.			1	
39	FRONT SKID	4-87-6	792-01-84	2	
40	REAR MONOCOQUE SKID	3-76-10	802-01-36	2	
41	M.F.B.H. SKID	3-76-10	802-01-36	2	
42	REAR CRASH HOOP	3-68-7	803-01-75	1	
43	DASH PANEL	3-48-4	782-01-21	1	
44	DASH PANEL MOUNTING RUBBER	8-20-4	TD8-20-4	3	
45	STEERING WHEEL	8-1-3	742-04-02	1	
46	" " RETAINING WASHER	4-2-4	712-04-07	1	
47	" " RIVET (STEEL)	8-1-4	TD 7	3	
48	STEERING COLUMN	3-59-10	792-04-09	1	
49	STEERING COLUMN SUPPORT	4-2-2	732-05-05	1	
50	STEERING RACK CLAMP	4-98-9	803-04-06	2	
51	" " MOUNTING PLATE	3-69-3	80A-04-02	2	
52	GEAR LEVER	49-1-2	782-11-08	1	
53	" " BADGE	8-6-10	782-11-05	1	
54	" CHANGE BRACKET	45-16-8	802-11-02	1	
55	" LEVER PIVOT	4-5-2	712-11-10	1	
56	" " SPACER	4-27-3	762-11-06	1	
57	" SHAFT	4-76-5	782-11-04	1	
58	" ROD MOUNTING	49-1-1	782-11-05	1	
59	" CHANGE BODY	4-79-1	782-11-03	1	
60	" " BEARING LINK	4-77-1	782-11-06	1	
61	LEFT FOOT REST	3-69-12	803-01-98	1	
62	FRONT SUSPENSION EAR PLATE	3-74-5	802-01-21	2	
63	F.B.W.B. D.S. PLATE	3-74-4	802-02-07	2	
64	THROTTLE CABLE BRACKET FRONT	3-62-5	792-01-87	1	
65	DAMPER MOUNTING STRUT	3-74-15	802-01-35	2	
66	SEAT BELT	8-1-11	TD 10	1	
67	" " BACKING PLATE	3-48-14	782-01-48	2	
68	" " PLATE-JOGGLED	2-1-2	722-01-75	2	
69	" " TOP MOUNTING BRACKET	3-63-10	792-01-132	4	
70	" " " " " SPACER	41-33-14	792-20-44	2	
71	FUEL TANK TOP	3-76-11	802-01-40	1	
72	REAR GEARSHIFT JOINT CIRCLIP	23-2-6	TD 1080		

MONOCOQUE CON.

Issue	Signature	Date
1	R. Scott	14.2.8

MONOCOQUE ASSEMBLY -802

Sheet 3 of 3

SECTION

	Item	Part No	DRG No.	No. Off	Detail
75	5.0 KG. FIRE BOTTLE	29- 1-8	TD 1008	1	
76	" " " " BRACKET	29-4-2	TD 29-4-2	1	
77	" " " " STRAPS	29-2-5	TD 1063	2	
78	FLEXIBLE HOSE	29-4-5	TD29-4-5	1	
79	DASH PANEL FIRE NOZZLE	4-44-4	763-22-01	1	
80	" " " " LOCK NUT	13-7-1	763-22-02	1	
81	2.5 KG. FIRE BOTTLE	29-1-10	TD 1009	1	
82	" " " " BRACKET	29-4-3	TD29-4-3	1	
83	" " " " STRAPS	29-2-4	TD 1062	2	
84	BUNDY PIPE	7-8-4	TD 7-8-4		
85	" " OLIVE	29-4-8	TD29-4-8	1	
86	" " NUT	29-4-7	TD29-4-7	1	
87	ENGINE BAY FIRE NOZZLE	4-84-9	79B-22-01	1	
88	" " " " NUT	7-8-7	TD 7-8-7	1	7/16 UNF MALE NU
89	LIFE SUPPORT BOTTLE	29-3-14	TD29-3-14	1	
90	" " " BRACKET	3-62-4	793-01-26	1	
91	" " " STRAPS			2	
92	" " HOSE	29-3-9	TD29-3-9		

FR. SUSP.

Issue	Signature	Da
1	P. Santiago	14.2

FRONT SUSPENSION - 802

Sheet 1 of 2

SECTION

	Item	Part No	DRG No.	No. Off	Detail
1	FRONT TOP ROCKER R.H.	32-5-10	802-02-04	1	
2	" " " L.H.	32-5-9	802-02-03	1	
3	ROCKER THRUST WASHER	41-32-13	792-20-28	4	
4	" BUSH	4-95-1	792-19-01	4	
5	" JOURNAL	4-63-7	792-02-16	2	
6	" THROUGH BOLT	12-24-7	792-02-15	2	
7	" OUTER JOINT SPACER INSERT	4-96-6	803-02-16	4	
8	" " " BOLT	4-96-9	803-06-09	2	
9	F.B.W.B. (LONG)	32-5-11	802-02-05	2	
10	" THRUST WASHER	41-32-13	792-20-28	16	
11	" BUSH	4-95-1	792-19-01	8	
12				4	
13				2	
14	" THROUGH BOLT	4-101-7	802-02-09	2	
15	" JOURNAL	4-2-5	732-02-07	4	
16	" OUTER JOINT SAFETY WASHER	4-82-14	802-06-07	2	
17	STEERING RACK ASSEMBLY			1	
18	RACK	4-92-14	803-04-01	1	
19	HOUSING	4-98-11	80A-04-01	1	
20	HOUSING EXTENSION	4-97-1	803-04-05	2	
21	PINION	8-23-14	TD8-23-14	1	
22	PINION BEARING	8-1-6	TD 28	2	
23	PINION BEARING SHIM	8-17-5	TD8-17-5	2	A.R.
24	PINION BEARING CLAMP RING	4-45-11	712-04-24	1	
25	END PLATE	8-17-4	TD8-17-4	1	
26	END PLATE CIRCLIP	8-17-3	TD8-17-3	1	
27	SPRING	41419	712-04-21	1	
28	SPRING STOP	4-4-10	712-04-22	1	
29	SPRING RETAINER	4-4-11	712-04-23	1	
30	TENSION CAP	4-4-8	712-04-19	1	
31	OILITE BUSH	8-18-5	TD8-18-5	2	
32	SEAL	8-9-6	TD 1022	2	
33	PINION SEAL (J.K. 6000 42C)	8-22-11	TD8-22-11		
34	TRACK ROD	4-102-5	802-04-02	2	8.92"
35	BUMP STEER SPACER (LARGE)	4-15-6	712-04-11		A.R.
36	BUMP STEER SPACER (SMALL)	4-24-10	712-04-12		A.R.

FR. SUSP. CON.

Issue	Signature	Date
1	R. Sawhney	14.2.8

FRONT SUSPENSION - 802

Sheet 2 of 2

	Item	SECTION Part No	DRG No.	No. Off	Detail
37	STEERING RACK CLEVIS	4-26-2	762-04-06	2	
38	" " " LOCK NUT	4-53-2	762-04-19	2	
39	F.A.R.B.	40-5-9	792-05-37	1	.735 DRILLED
40	" MOUNTING BLOCK	4-102-12	802-05-03	2	
41	" LINK	4-93-12	803-05-05	2	
42	" ARM	3-68-8	803-05-04	2	
43	" " JOINT INSERT	4-93-7	803-05-02	4	
44	" LINK BOTTOM JOINT BOLT	4-93-8	803-05-01	2	
45	FRONT SPRING			2	500 lb x 6"
46	FRONT DAMPER	16-2-11	TD16-2-11	2	1401 B15
47	" " INSERT (BOTTOM)	4-2-12	712-02-09	4	
48	" " " (TOP)	4-82-13	80A-02-04	2	
49	" " BOTTOM MOUNTING BOLT	4-92-15	803-02-13	2	

REAR SUSP.

Issue	Signature	Dat
1	R. Sautrey	14.2

REAR SUSPENSION - 802

	Item	SECTION Part No	DRG No.	No. Off	Detail
1	REAR TOP ROCKER L.H.	32-5-13	802-03-09	1	
2	" " " R.H.	32-5-12	802-03-10	1	
3	" " " BOLT	4-100-5	802-03-03	2	
4	" " " JOURNAL	4-100-4	802-03-04	2	
5	" " " BUSH	4-95-1	792-19-01	4	
6	" " " THRUST WASHER	41-32-13	792-20-28	4	
7	ROCKER OUTER JOINT CIRCLIP	23-5-13	TD23-5-13	2	NAM 1300-150
8	REAR BOTTOM WISHBONE L.H.	32-5-15	802-03-01	1	
9	" " " R.H.	32-5-14	802-03-02	1	
10	TRACK CONTROL ARM	4-100-3	802-03-11	2	
11	R.B.W.B. FRONT MOUNT BRACKET	4-100-13	802-03-17	3	
12	" INNER JOINT CIRCLIP	23-5-10	TD23-5-10	4	
13	" " " " SHIM	41-32-5	708-16-03	A.R.	.060/.062
14	" " " " "	41-32-7	792-20-22	A.R.	.055/.057
15	" " " " "	41-32-8	792-20-23	A.R.	.065/.067
16	" " " " "	41-7-5	802-20-26	A.R.	.028/.030
17	" " " " "	41-7-6	802-20-27	A.R.	.033/.035
18	" " SPACER	41-6-12	802-20-16	4	
19	" " "	41-6-13	802-20-17	4	
20	" " "	41-6-15	802-20-21	4	
21	" " INSERT	41-6-8	802-03-16	8	
22	REAR SPRING			2	750 LB x 7"
23	" DAMPER	16-2-15	TD 16-2-15	2	1406 B 7
24	R.A.R.B./DAMPER CLEVIS BOLT	4-100-6	802-03-14	2	
25	REAR ROCKER/DAMPER D.S. PLATE L.H.	3-74-7	802-03-13	1	
26	" " " " R.H.	3-74-8	802-03-12	1	
27	DAMPER INSERT	4-61-8	771-03-22	8	
28	REAR ANTI-ROLL BAR	40-5-12	802-05-01	1	
29	R.A.R.B. BLADE	4-102-14	802-05-07	2	
30	" MOUNTING BLOCK	4-102-15	802-05-03	2	
31	REAR LOWER DAMPER BRKT L.H.	3-74-9	802-01-01	1	
32	" " " " R.H.	3-74-10	802-01-02	1	
33	R.B.W.B. ANCHOR PLATE	4-100-8	802-01-04	1	
34	REAR LOWER DAMPER BEAM	4-100-7	802-01-03		
35	ANCHOR PLATE D.S. PLATE	3-74-6	802-01-05		
36	REAR ROCKER SUPPORT EAR L.H.	4-103-1	802-01-16	1	
37	" " " " R.H.	4-103-2	802-01-17	1	

REAR SUSP. con

Issue	Signature	Da
1	R. Santiago	14.2

REAR SUSPENSION - 802

Sheet 2 of 2

SECTION

	Item	Part No	DRG No.	No. Off	Detail
38	R.B.W.B. REAR GEAR ROD MTG.	4-104-8	802-03-25	1	
39	R.B.W.B. BRACE L & R.H.	3-77-10/11	802-01-53/4	2	1 Each Hand
40	REAR ROCKER SUPPORT PLATE L.H.	4-104-1	802-01-29	1	
41	REAR ROCKER SUPPORT PLATE R.H.	4-104-2	802-01-28	1	
42	R.V.A.R.B. OPERATING MECHANISM COMPRISES:				
43	R.A.R.B. TIE	4-104-6	802-05-08	1	10¼" Long
44	" " CLAMP L.H.	4-104-3	802-05-09	1	
45	" " CLAMP R.H.	4-104-4	802-05-12	1	
46	" ADJUSTING CABLE	34-2-2	TD34-2-2	1	2.25 M.
47	" " CLEVIS	8-24-10	TD8-24-10	1	
48	" " CABLE SUPPORT	4-104-7	802-05-11	1	
49	" " " CLAMP	8-16-14	TD 8-16-14	2	
50	" " " " SPACER	3-36-14	772-01-06	2	
51	" BLADE BEARING	8-24-9	TD 8-24-9	4	DURKOPP k 19 23 x 13
52	" TIE CLAMP CIRCLIP	23-5-14	TD23-5-14	2	
53	" THRUST WASHER	4-104-5	802-05-02	4	
54	" OPERATING LEVER	3-77-15	802-05-14	1	
55	" " " WAVED WASHER	20-4-8	TD 20-4-8	1	501/25
56	" " " THRUST WASHER	41-7-3	802-20-24	2	
57	" " " SPIGOT	42-3-9	802-19-07	1	
58	" " " 2BA Washer	20-2-3	TD 352	1	Large O/D.
59	" " " MOUNT	3-78-1	802-05-15	1	
60	ADJUSTING CABLE STOP	41-7-4	802-20-25	1	
61	OIL TANK/R.L.W.B.MTG. STUD	4-104-10	802-16-27	8	¼ x 1.37
62	" " /R.T.R. CAST EAR STUD	4-104-11	802-16-28	8	5/16" x 1.31

FR. UPRIGHTS.

Issue	Signature	
1	R. Sawkins	14

FRONT UPRIGHTS- 802

SECTION

	Item	Part No	DRG No.	No. Off	Detail
1	FRONT UPRIGHT ASSY. COMPRISES:			2	
2	UPRIGHT	4-89-15	802-06-03	1	
3	FRONT AXLE	4-27-7	751-06-01	1	
4	" " DRIVE PIN	4-1-9	711-07-04	3	
5	WHEEL BEARING	8-1-5	TD 1	2	
6	" " SPACER	4-1-5	711-06-07	1	
7	OUTER SPACER	4-1-13	711-07-05	1	
8	WHEEL STUD ASSEMBLY	3-68-4	803-06-07	1	
9	" " SPIROL PIN	8-1-7	TD 154	2	
10	BRAKE DISC	7-1-5	TD 116	1	
11	" " BELL	4-66-6	802-06-02	1	
12	BOTTOM PIN	4-92-4	802-06-01	1	
13	BOTTOM PIN SPACER	4-92-5	802-06-04	1	
14	UPRIGHT D.S. PLATE	3-68-3	802-06-05	2	
15	" " " SPACER	4-91-15	802-06-06	1	
16	" " " " STUD	4-93-3	803-06-10	4	
17	WHEEL WASHER	4-52-2	771-09-01	1	
18	" " INSERT	4-6-11	712-07-11	1	
19	FRONT WHEEL	19-5-3	782-09-09	2	13 x 10" C
20	FRONT TYRE			2	
21	DISC BELL BOLT	4-59-8	771-10-17		
22	" " " NUT	13-2-6	TD13-2-6		

REAR UPRIGHT.

Issue	Signature	Date
1	R. Santos	14.2.8

REAR UPRIGHT - 802

SECTION

	Item	Part No	DRG No.	No. Off	Detail
1	UPRIGHT	4-100-12	802-07-02	2	
2	REAR AXLE	4-93-6	802-07-01	2	
3	" " DRIVE PIN	4-1-9	711-07-04	12	
4	WHEEL BEARING	8-1-5	TD 1	4	SKF SKF 6010 [illegible]
5	" " SPACER	4-1-5	711-06-07	2	1.375
6	OUTER SPACER	4-1-13	711-07-o5	2	
7	BRAKE DISC	7-1-5	TD116	2	
8	BRAKE DISC BELL	4-66-6	802-06-02	2	
9	" " " BOLT	4-59-8	771-10-17	12	
10	" " " NUT	13-2-6	TD 13-2-6	12	¼ UNF AEROTIGHT
11	BOTTOM PIN	4-92-4	802-06-01	2	
12	" " SPACER	4-92-5	802-06-04	2	
13	R.B.W.B. OUTER JOINT SAFET WASHER	4-82-14	802-06-07	2	
14	R.T. ROCKER OUTER JOINT BOLT	4-100-11	802-03-05	2	
15	" " " " SAFETY WASHER	4-100-9	802-07-03	2	
16	" " " " SPACER	4-100-10	802-07-04	2	
17	REAR TRACK CONTROL ARM SPACER	4-82-15	802-07-05	2	
18	" " " " SAFETY WASHER	4-102-10	~~792-03-14~~	2	802-07-06
19	WHEEL WASHER	4-52-2	771-09-01	2	
20	WHEEL WASHER INSERT	4-6-11	712-07-11	2	
21	REAR WHEEL	19-5-12	802-09-01	2	14" RIM x 5½ OFFS
22	REAR TYRE			2	

PEDALS.

Issue	Signature	Dat
1	R. Saulnag	14.7.

PEDALS - 802

	Item	SECTION Part No	DRG No.	No. Off	Detail
1	CLUTCH PEDAL ASSEMBLY COMPRISES:			1	
2	CLUTCH PEDAL	2-10-12	803-08-02	1	
3	CLUTCH PEDAL PIVOT BEARING	8-1-10	TD 126	2	06 DU 08
4	CLUTCH PEDAL CLEVIS BEARING	8-18-1	TD8-18-1	1	
5	CLUTCH CLEVIS	4-26-11	771-08-04	1	
6	CLUTCH CLEVIS PIN	4-56-14	771-08-09	1	
7	CLUTCH PEDAL PIVOT BUSH	4-5-11	712-08-07	1	
8	BRAKE PEDAL ASSEMBLY COMPRISES:				
9	BRAKE PEDAL	3-24-9	792-08-01	1	
10	BRAKE PEDAL PIVOT BEARING	8-1-10	TD 126	2	06 DU 08
11	BALANCE BAR SHAFT	4-103-11	802-08-01	1	
12	BRAKE PEDAL PIVOT BUSH	4-5-11	712-08-07	1	
13	BALANCE BAR YOKE	4-5-14	703-08-01	2	
14	BALANCE BAR YOKE INSERT	4-5-13	703-08-03	2	
15	BALANCE BAR NUT	4-6-1	703-08-02	2	
16	THROTTLE PEDAL ASSEMBLY COMPRISES:				
17	THROTTLE PEDAL	3-24-11	792-08-03	1	
18	THROTTLE PEDAL PIVOT BEARING	8-1-10	TD 126	2	06 DU 08
19	THROTTLE PEDAL PIVOT BUSH	4-5-11	712-08-07	1	
20	CLUTCH PEDAL BUFFER RUBBER	8-16-11	TD8-16-11	1	
21	CLUTCH PEDAL BUFFER SUPPORT	4-64-15	771-01-81	1	
22	THROTTLE STOP	3-71-3	80V-13-01	1	
23	ADJUSTABLE BRAKE BALANCE	3-77-4	802-08-02	1	
		4-59-15	782-01-56	1	

ENG. INST.

Issue	Signature	D.
1	R. Gaulzego	14.

ENGINE INSTALATION- 802 BMW

Sheet 1 of 2

	Item	SECTION Part No	DRG No.	No. Off	Detail
1	ENGINE (SUPPLIED BY CUSTOMER)	-----	---	1	
2	CLUTCH (SUPPLIED WITH ENGINE)	-----	---	1	
3	ENGINE SIDEFRAME L.H.	36-3-9	802-01-23	1	
4	ENGINE SIDEFRAME R.H.	36-3-10	802-01-22	1	
5	ENGINE MOUNT LOWER BEAM	4-100-14	802-01-24	1	
6	ENGINE MOUNT UPPER BEAM	4-100-15	802-01-26	1	
7	ENGINE MOUNT TOP PLATE	3-74-11	802-01-27	1	
8	SIDEFRAME CLEVIS	4-94-1	803-01-73	2	
9	SIDEFRAME STUD TOP	4-101-6	802-01-34	2	
10	" " BOTTOM	4-93-10	803-01-67	2	
11	ADAPTOR PLATE	4-103-5	802-16-21	1	
12	" " OIL TANK	4-101-1	802-16-10	2	
13	" " G.BOX STUD (MID)	4-101-2	802-16-11	2	
14	" " G.BOX STUD (MID UPPER)	4-101-3	802-16-12	1	
15	" " GEARBOX STUD (TOP)	4-101-4	802-16-14	2	
16	BOTTOM ENGINE/GEARBOX STUD	4-101-8	802-16-09	2	
17	STARTER MOTOR (SUPPLIED WITH ENGINE	—	--	-	
18	STARTER MOTOR STUD	4-101-5	802-16-15	1	
19	FLYWHEEL STONE GUARD	1-1-13	73S-16-05	1	
20	EXHAUST SYSTEM	24-3-14		1	
21	" BRACKET	3-76-13		1	
22	TACHOMETER	34-1-1	TD958	1	
23	" DRIVE	8-3-3	TD 64	1	
24	OIL PRESSURE LINE	21-2-7	TD 290		-3 AEROQUIP
25	" " " UNION	21-1-3	TD 701	1	-3 90 "
26	" " TAKE OFF ADAPTOR	4-80-2	762-16-19		
27	" " GAUGE	8-3-5	TD 67	1	10 FT.
28	FUEL " LINE	21-2-7	TD 290		-3 AEROQUIP
29	" " " UNION	21-1-3	TD 701	1	-3 90 "
30	" " SENDER UNIT	4-94-7	802-15-04	1	
31	WATER TEMP. GAUGE	34-1-14	TD 34-1-14	1	8 FT.
32	AIRBOX	11-8-15	782-12-43	1	
33	AIRBOX BASE	3-35-8	782-01-96	1	
34	" " CLAMP	3-18-9	752-01-110	2	
35	" " SEALING RING	35-2-1	782-01-51	4	
36	" STONEGUARD	2-10-5	782-12-19		

ENG. INST. CON.

Issue	Signature	Da
1	R. Saulnop	14.

ENGINE INSTALATION - 802 BMW

Sheet 2 of 2

	Item	SECTION Part No	DRG No.	No. Off	Detail
37	THROTTLE CABLE	8-17-10	TD8-17-10	1	2 M.
38	" " CLAMP	8-16-14	TD8-16-14	2	
39	" " CONNECTOR	4-45-6	762-16-42	1	
40	" " CLAMP SPACER	3-36-14	772-01-06	2	
41	BOWDEN INNER CABLE	8-2-2	TD 31		
42	" OUTER "	8-2-1	TD 30		
43	NIPPLE	8-2-5	TD 34	1	
44	SIDEFRAME CLEVIS/MONOCOQUE SPACER	41-6-11	802-20-15	2	

TRANSMISSION.

Issue	Signature	Date
1	R Saulago	14.2.80

TRANSMISSION - 802

SECTION

	Item	Part No	DRG No.	No. Off	Detail
1	GEARBOX	18-3-3	TD 18-3-3	1	FT 200
2	" MODIFICATIONS	4-101-9	802-16-03		
3	" SIDEPLATE L.H.	4-101-11	802-16-01	1	
4	" " R.H.	4-101-10	802-16-02	1	
5	" " STUD	4-99-7	802-16-05	3	
6	" " "	4-99-8	802-16-06	6	
7	" " "	4-99-9	802-16-07	6	
8	IMPUT SHAFT (BMW)			1	
9	IMPUT SHAFT (HART) (FT 23936)			1	
10	CLUTCH RELEASE BEARING			1	SKF 360801
11	" " PISTON	4-101-12	802-14-05	1	
12	OIL TANK/CLUTCH RELEASE PISTON SEAL	8-24-3	TD 8-24-3	1	CP 2383/14
13	CLUTCH RELEASE PISTON BALL	8-24-4	TD 8-24-4	1	
14	NOSE PIECE	4-101-13	802-14-04	1	
15	O RING (NOSE PIECE TO COVER PLATE)	8-21-11	TD 8-21-11	1	GACO R3137
16	O RING (NOSE PIECE TO OIL TANK)	8-21-10	TD 8-21-10	1	
17	CLUTCH RELEASE PISTON /NOSE PIECE SEAL	8-24-5	TD 8-24-5	1	DOWTY O-RING BSO
18	GEARBOX END COVER	4-99-4	802-16-04	1	
19	" OIL FILTER ASSEMBLY COMPRISES:		782-16-22	1	
20	GEARBOX OIL FILTER WASHER	4-103-6	802-16-22	1	
21	SEAL	8-21-1	TD 8-21-1	1	
22	FILTER TUBE	4-81-13	782-16-21	1	
23	FILTER ELEMENT	8-13-9	TD8-13-9	1	
24	WASHER	4-61-6	771-16-38	1	
25	OIL FILTER END COVER	4-81-14	782-16-20	1	
26	" " BOLT	4-102-9	802-16-23	1	
27	" " " O-RING	8-14-10	TD8-14-10	1	GACO R2050
28	SPRING	16-6-2	771-16-39	1	
29	OIL FILTER SPINDLE	4-103-7	802-16-24	1	
30	OIL FILTER OUTLET UNION	21-1-9	TD 313	1	-6 90
31	" PUMP RETURN PIPE	21-2-9	TD 292		-6 HOSE
32	GEARBOX INLET UNION	21-1-7	TD 299	1	
33	" " BANJO	4-87-13	792-16-10	1	
34	" " " BOLT	4-103-8	792-16-11	1	
35	" " SPRAY TUBE	4-94-11	792-14-09	1	
36	SPRAY TUBE DOWTY SEAL	20-3-14	TD 20-3-14	1	¾" BSP
37	INLET BANJO " "				

TRANSMISSION. CON.

Issue	Signature	Date
1	R. Santiago	14.2.80

TRANSMISSION - 802

Sheet 2 of 2

SECTION

	Item	Part No	DRG No.	No. Off	Detail
38	DRIVESHAFT ASSEMBLY COMPRISES:			2	
39	DRIVESHAFT	4-29-13	802-10-01	1	
40	PLUNGE JOINT HOUSING/OUTPUT SHAFT SHIM	3-76-14	802-16-08	1	
41	" " "	14-2-9	782-10-03	1	
42	" " " BOLT	12-13-8	TD 591	6	
43	" " CAGE	14-1-7	TD 176	1	
44	" " BALL	14-1-8	TD 175	6	
45	" " INNER TRACK	14-1-6	TD 179	1	
46	" " GAITER	14-2-11	TD 14-2-11	1	
47	DRIVESHAFT INNER CIRCLIP	8-1-9	TD 174	1	
48	DRIVESHAFT OUTER CIRCLIP	23-5-5	TD23-5-5	1	
49	DRIVESHAFT YOKE	14-2-4	741-10-08	1	
50	CENTRE CROSS	14-2-2	TD 192	1	
51	AXLE YOKE	14-2-1	741-10-02	1	
52	" " THRUST RING	4-18-13	741-10-03		
53	WHEEL RETAINNING STUD	4-103-9	802-07-07	1	
54	FRONT GEAR ROD	3-77-14	802-11-01	1	
55	MIDDLE GEAR ROD			1	
56	REAR " "			1	
57	GEARBOX -DAMPER BEAM STUD	4-101-15	802-16-16	2	
58	" BTM W.B. PLATE STUD	4-102-1	802-16-17	2	
59	G.BOX SIDEPLATE - R.A.R.B. BLOCK STUD	4-102-2	802-16-18	4	
60	" " - R.T.R. EAR STUD	4-102-3	802-16-19	2	
61	G.BOX SIDEPLATE BRACE	3-77-6	802-16-26	1	
62	G.BOX END COVER BUNG	4-8-12	753-15-06	1	-6 PLUG

OIL SYSTEM.

Issue	Signature	
1	P. Santiago	14

OIL SYSTEM - 802

SECTION

	Item	Part No	DRG No.	No. Off	Detai
1	OIL TANK	4-100-2	802-14-01	1	
2	" " COVER	3-74-14	802-14-02	1	
3	" " /GEARBOX STUD (MID UPPER)	4-101-14	802-16-13	1	
4	" " " " (MID LOWER)	4-104-9	802-16-20	2	
5	OIL TANK CAP	4-20-1	722-18-11	1	
6	" " " O-RING	8-8-9	TD 70	1	
7	FILTER ASSEMBLY	3-61-2	792-14-05	1	
8	" " SEAL	20-3-10	TD 20-3-10	1	1" BSP DOWT
9	TEMP TAKE OFF BOSS	4-33-3	762-14-04	1	
10	" " " " SEAL	20-3-10	TD20-3-10	1	1" BSP DOWT
11	OIL TANK UNION	4-102-7	802-14-06	2	
12	" " " O-RING	8-21-12	TD 8-21-12	3	GACO R2062
13	OIL TANK CORE PLUG	8-24-6	TD8-24-6	2	1970/2g
14	" " NECK		802-14-09	1	
15	" " " SEALING RING	8-21-13	TD8-21-13	1	GACO R 3250
16	OIL COOLER	8-11-7	TD8-11-7	1	13 ROW
17	OIL COOLER MOUNTING BRACKET	3-77-12	802-01-55	1	
18	OIL BAFFLE POT	3-77-7	802-14-07	1	
19	OIL TANK SKID	3-77-8	802-01-25	2	
20	OIL TANK BREATHER ELBOW	3-78-2	802-14-08	1	
21	TANK COVER SEALING RING	8124-12	TD 8-24-12	1	SILICONE CC .08/.085

WATER SYSTEM.

Issue	Signature	Date
1	R. Santiago	14.2.8

WATER SYSTEM - 802

SECTION

	Item	Part No	DRG No.	No. Off	Detail
1	RADIATOR L.H.	27-4-13	802-13-01	1	6 ROW
2	" R.H.	27-4-12	802-13-02	1	

FUEL SYSTEM.

Issue	Signature	Date
1	R. Santiago	14.2.80

FUEL SYSTEM - 802

SECTION

	Item	Part No	DRG No.	No. Off	Detail
1	FUEL TANK	17-2-14	792-15-01	1	
2	COLLECTOR POT	3-72-13	80A-15-02	1	BONDED INTO TANK
3	" " FILTER STEM	3-61-4	792-15-05	1	
4	" " FILTER ELEMENT	8-23-5	792-15-07	1	
5	TANK OUTLET ADAPTOR	4-35-14	792-15-06	1	
6	COLLECTOR POT - OUTLET HOSE	21-2-10	TD 293		-8 AEROQUIP
7	TANK OUTLET UNION (INNER)	21-1-12	TD 314	1	-8 90
8	" " " (OUTER)			1	-8
9	OUTLET - PUMP HOSE	21-2-10	TD 293		-8 AEROQUIP
10	FUEL PUMP INLET UNION			1	-8
11	FUEL PUMP	8-16-8	TD 8-16-8	1	BOSH
12	" " INLET ADAPTOR	4-89-6	792-15-18	1	
13	" " " " SEAL				
14	" " OUTLET ADAPTOR	4-71-9	782-15-05	1	
15	" " , " SEAL	20-3-7	TD 20-3-7		
16	PUMP - METERING UNIT HOSE	21-2-9	TD 292		-6 AEROQUIP
17	PUMP OUTLET UNION			1	-6
18	METERING UNIT INLET UNION	21-1-8	TD 306	1	-6
19	METERING UNIT INLET BANJO	4-80-6	782-15-18	1	
20	" " FILTER ELEMENT	4-76-14	783-15-05	1	
21	" " BANJO BOLT	4-80-5	782-15-17	1	
22	" " OUTLET ADAPTOR	4-16-6	75S-13-14	1	¼"BSP STEEL WELD
23	" " " UNION	21-1-3	TD 701	1	-3 90
24	" " RETURN HOSE	21-2-7	TD 290		-3 AEROQUIP
25	FUEL TANK RETURN UNION				-3
26	FUEL PUMP BRACKET	3-77-5	802-15-05		
27	FUEL TANK CAP	4-20-1	722-18-11	1	
28	" " " O-RING	8-8-9	TD 70	1	
29	" " TOP SEAL	8-24-11	TD8-24-11	1	
30	" " BREATHER HOSE				
31	" " " VALVE	4-103-14	802-15-08	1	

SPHERICAL JOINTS

Issue	Signature	Date
1	R. Sutton	14.7.80

SPHERICAL JOINTS - 802

	Item	SECTION Part No	DRG No.	No. Off	Detail
1	FRONT TOP ROCKER OUTER	15-4-3	TD15-4-3	2	RBF 8B
2	F.B.W.B. OUTER	15-4-2	TD15-4-2	2	RA 10
3	TRACK ROD OUTER	15-3-3	TD15-3-3	2	RMLR 5 UF
4	" " INNER	15-3-2	TD15-3-2	2	RMR 5 UF
5	F.A.R.B. LINK TOP	15-3-2	TD15-3-2	2	RMR 5 U
6	" " BTM	15-3-3	TD15-3-3	2	RMLR 5U
7	REAR TOP ROCKER OUTER	15-4-3	TD15-4-3	2	RBF 8B
8	R.B.W.B. INNER	15-2-3	TD 56	4	RSTWR 08E
9	R.B.W.B. OUTER	15-4-2	TD15-4-2	2	RA 10
10	REAR TRACK ROD INNER	15-1-14	TD 52	2	RC 6E
11	" " " OUTER	15-3-9		2	RCL 7
12	R.A.R.B. LINK TOP	15-4-4	802-o3-18	2	RBJ 10 U (MOD)
13	" " BOTTOM	15-4-5	802-o3-19	2	RBJ 67 U (MOD)
14	GEARLEVER LOCATION BEARING	15-2-12	TD1013	2	RBJ 67 U
15	THROTTLE PEDAL /CABLE JOINT	15-2-7	TD 15-2-7	1	RF 3U
16	MIRROR MOUNT	4-73-11	782-12-25	2	RMP 4U (MOD)
17	GEARSHIFT BEARING	15-2-13	TD 1012	2	RAC 12
18	R.A.R.B. ADJUSTING TIE	15-2-7	TD15-2-7	2	RF 3U

1/28 LG

0.12 (0.8UNF)

HYDRAULICS.

Issue	Signature	Date
1	R.Sa[illegible]	14.2.8[illegible]

HYDRAULICS 802

Sheet 1 of 2

SECTION

	Item	Part No	DRG No.	No. Off	Detail
	FRONT BRAKES				
1	MASTER CYLINDER	7-3-14	TD 1078	1	.75
2	" " RESERVOIR	7-3-13	TD 1120	1	
3	" " " SEAL	20-3-7	TD 20-3-7	1	7/16" I.D. DOWT[illegible]
4	" " DIAPHRAGM	7-7-12		1	
5	BANJO BOLT	7-3-8	TD 690	1	
6	BANJO	7-3-5	TD 691	1	
7	⅛" B.S.P - ⅜" UNF ADAPTOR	4-8-7	732-06-18	2	
8	AEROQUIP -3 HOSE	21-2-7	TD 290		
9	" -3 90 UNION	21-1-3	TD 701	2	
10	" -3 30 BANJO	21-4-3	TD21-4-3	2	
11	" -3 BANJO BOLT	21-4-4	TD21-4-4	2	
12	CALIPER	7-2-1	TD 107	2	
13	BRAKE PAD	7-2-8	TD 276	4	
	MASTER CYLINDER PUSH ROD -LONG	7-1-7	TD 7-1-7	1	OPTIONAL
	REAR BRAKES				
14	MASTER CYLINDER	7-3-14	TD 1078	1	.75"
15	" " RESERVOIR	7-3-13	TD 1120	1	
16	" " " SEAL	20-3-7	TD 20-3-7	1	7_16" I.D. DOWT
17	" " DIAPHRAGM	7-7-12			
18	" " PUSH ROD - LONG	7-1-7	TD 7-1-7	1	OPTIONAL
19	⅛" B.SP./⅜" UNF ADAPTOR	4-8-7	732-06-18	4	
20	REAR BULKHEAD ADAPTOR	4-102-6	802-26-02	1	-3 to -3
21	" " " LOCK NUT	13-5-8		1	⅛"B.S.P. HALF N
22	TEE PIECE	7-3-9	TD 696	1	
23	AEROQUIP HOSE -3	21-2-7	TD 290		
24	" UNION -3 x BANJO			1	
25	" " -3 x 30 BANJO	21-4-3	TD21-4-3	2	
26	" " -3 BANJO BOLT	21-4-4	TD21-4-4	3	
27	" " -3 x STRAIGHT	21-1-1	TD 697	4	
28	REAR CALIPER	7-2-1	TD 107	2	
29	BRAKE PAD	7-2-8	TD 276	4	

HYDRAULICS CON.

Issue	Signature	Date
1	R. Sa[illegible]	14.2.8[illegible]

HYDRAULICS - 802

Sheet 2 of 2

SECTION

	Item	Part No	DRG No.	No. Off	Detail
	CLUTCH				
30	MASTER CYLINDER	7-3-14	TD1078	1	.75"
31	" " RESERVOIR	7-3-13	TD 1120	1	
32	" " " SEAL	20-3-7	TD20-3-7	1	7/16" DOWTY
33	" " DIAPHRAGM	7-7-12		1	
34	" " PUSH ROD -LONG-	7-1-7	TD 7-1-7	1	OPTIONAL
35	⅛" B.S.P./⅜" UNF ADAPTOR	4-8-7	732-06-18		
36	REAR BULKHEAD ADAPTOR	4-102-6	802-26-02	1	
37	" " " LOCK NUT	13-5-8	TD13-5-8		⅛"BSP HALF NUT
38	AEROQUIP -3 HOSE	21-2-7	TD 290		
39	" -3 90 UNION	21-1-3	TD 701	1	
40	" -3 BANJO x 30	21-4-3	TD21-4-3	1	
41	" -3 BANJO BOLT	21-4-4	TD 21-4-4	1	
42	THIN COPPER WASHER	20-2-14	TD20-2-14	6	
43	ADAPTOR	4-8-7	732-06-18	3	
44	AEROQUIP -3 45 UNION	21-1-2	TD 699	1	
45	AEROQUIP -3 90 UNION	21-1-3	TD 701	3	
46	AEROQUIP -3 HOSE	21-2-7	TD 290		
47	OIL TANK CLUTCH BLEED	4-102-11	802-25-01	1	
48	OIL TANK CLUTCH BLEED LOCK NUT	13-5-8	TD 13-5-8	1	
49	CLUTCH BLEED NIPPLE			1	

ELECTRICS.

Issue	Signature	Date
1	R. Santag	14.2.80

ELECTRICS 802

	Item	SECTION Part No	DRG No.	No. Off	Detail
1	BATTERY				
2	" CABLE				
3	" TERMINAL				
4	" " CAP				
5	MASTER SWITCH ASSEMBLY	35-2-4	80A-28-06	1	
6	FIRE PULL HANDLE	3-71-7	803-22-01	1	
7	" " CONNECTOR	4-97-12	803-01-100	1	
8	" " BRACKET	3-71-5	803-01-99	1	
9	" " " GROMMET	8-18-9	TD8-18-9	1	
10	" " CABLE INNER	8-2-2	TD 31		
11	" " " OUTER	8-2-1	TD 30		
12	" " " ADJUSTER	8-2-3	TD 32	2	
13	" " " " SUPPORT	8-2-14	TD 39	2	
14	" " " FERRULE	8-2-4	TD 33	2	
15	" " " NIPPLE	8-2-5	TD 34	2	
16	" " " CLEVIS	8-2-6	TD 35	1	
17	" " " " PIN	8-2-7	TD 36	1	
18	RED PLASTIC SLEEVE	8-18-13	TD 8-18-13	5"	
19	MASTER SWITCH MTG. PACKER	3-77-13	802-28-01-	1	
20	FIRE EXTINGUISHER BUTTON (DASH)	9-1-2	TD 274	1	
21	STARTER BUTTON	9-1-2	TD 274	1	
22	FIRE EXTINGUISER MASTER SWITCH	9-1-12	TD 426	1	
23	FUEL PUMP SWITCH	9-1-12	TD 426	1	
24	IGNITION SWITCH	9-1-12	TD 426	1	
25	KILL SWITCH	9-1-12	TD 426	1	
26	REAR LIGHT SWITCH	9-1-12	TD 426	1	
27	REAR LIGHT	9-9-7		1	
28	WIRING LOOM			1	
29	OIL PRESSURE SWITCH	9-4-6	TD 951	1	
30	OIL PRESSURE WARNING LIGHT	9-9-6	TD9-9-6	1	
31	JUMP PLUG	9-5-13	TD 1101	1	
32	" " SOCKET	9-5-12	TD 1101	1	
33	" " CAP	9-6-9	TD 1102	1	
34	" " SOCKET BRACKET			1	
35	FIRE POWER PACK	29-1-6	TD 1006	1	

Bodywork.

Issue	Signature	Date
1	R. Santiago	14.7.82

BODYWORK - 802

SECTION

	Item	Part No	DRG No.	No. Off	Detail
1	NOSE			1	
2	NOSE FRAME ASSEMBLY		802-01-	1	
3	FRONT WING	46-5-3	802-12-15	2	9" CORD
4	FRONT WING SUPPORT BAR	3-61-13	802-12-16	1	
5	FRONT WING SIDE PLATE	46-5-4	802-12-17	2	
6	FRONT WING END CAP	3-61-11	792-12-18	2	
7				2	
8	NOSE PLATE MOUNTING BRACKET (BOTTOM)	3-76-15	802-01-32	2	
9	" //FRAME MOUNTING BRACKET			2	
10	COCKPIT			1	
11	FUEL TOWER CRUSHABLE L.H.	11-12-7		1	
12	" " " R.H.	11-12-8		1	
13	COCKPIT SCREEN	11-7-11			
14	" " BOLT	12-2-9	TD12-2-9	13	2BA Nylon x ¾"
15	" " NUT	13-1-10	TD 13-1-10	13	2BA Washer Faced
16	MIRROR L.H.	11-11-13		1	
17	MIRROR R.H.	11-11-14		1	
18	SIDEPOD L.H.			1	
19	SIDEPOD R.H.			1	
20	HEADREST	11-11-15		1	
21	HELMETREST	11-12-4		1	
22	SEAT	11-12-5			
23	REAR WING SUPPORT STRUCTURE		802-12-08	1	
24	REAR WING MOUNTING ASSEMBLY		802-12-19	1	
25	REAR LIGHT MOUNTING BRACKET			1	
26	WING MAINPLANE	46-2-5		1	
27	WING FLAP	46-2-6		1	
28	SIDEPLATE	[illegible]	802-12-[illegible]	[illegible]	
29	L - FLAP (WING)	3-53-6	792-12-[illegible]	1	